# INSTALLATION INSTRUCTIONS: 66-77 Bronco Stainless Steel Braided Brake Hoses

# James Duff Inc. The Bronco Specialists since 1967

## **PART# 3931**

These hoses not only meet all DOT, TUV & JWA standards and specifications for flexible hoses including SAE J 1401 (Jan 81) and FMVSS 106-74-38 FR31302 1973, they are individually inspected and tested before shipment. Batch testing, the industry standard, is not acceptable. Each individual hose assembly is pressure tested at 4000 psi after manufacture.

865.938.6696 www.jamesduff.com 3231 NW Park Dr. Knoxville, TN 37921

1/1 11/06

NOTE: Read instructions completely before beginning. Be certain you have all required parts, materials and tools and that you know where they go and how to use them. Reread each step as you go.

### **INSTRUCTIONS:**

- 1. Being careful not to get brake fluid on paint work, drain the system of brake fluid.
- 2. Remove the stock hoses. To avoid rounding the corners of the fittings, soak the threads of the fittings which connect the hard lines to the flexible rubber hoses with penetrating oil and use a properly sized line wrench.
- 3. Remove and discard all of the old crush washers. Carefully clean the sealing surfaces.
- 4. Clean and inspect all of the adapters and banjo bolts. Replace any damaged parts.
- 5. Make sure that your new stainless hoses are clean and dry. Even minute amounts of debris and/or water can damage your braking system.
- 6. Install the new stainless hoses using the original banjo bolts. Use the new crush washers supplied with the kit. Do not fully tighten the banjo bolts or threaded hose ends until step 7 is completed.
- 7. We make every effort to ensure that our hoses will properly fit the entire model range. However, the vehicle manufacturers sometimes make detail changes within a model year. Therefore each hose installation must be checked for correct length, routing and clearance. The hose must be installed without twists or kinks and the installation at each wheel must be checked through full travel of both suspension and steering to ensure that the hoses are not stretched or kinked and that there is no possible interference or abrasion.
- 8. Tighten all fluid connections. Tighten the fittings connecting the hard lines to the stainless hoses first. Then tighten the banjo bolts or threaded hose ends, making certain that the hoses are twist free. To ensure that the hoses are twist free, the ends are radically adjustable at either the hard line adapter or at the intersection between the elastomeric hose and the stainless braid protected Teflon hose.
- 9. Bleed the system in accordance with the vehicle manufacturer's instructions. Use only fresh brake fluid meeting DOT 3 specifications or above.
- 10. Before driving the vehicle, pump the brake pedal several times to force the pads against the discs and make a final inspection to ensure that all fluid connections are tight and leak free under full line pressure.

#### **LIMITED WARRANTY**

James Duff Inc. warrants our products to the original purchaser to be free from defects in materials and workmanship. Warranty periods begin at the date of purchase and varies by product. Shocks have a limited lifetime warranty. Headers, Radiators and Suspension Products have a one year warranty. Power Brake Boosters and Master Cylinders have a three year warranty. Adapters and soft goods such as Canvas tops, upholstery, vinyl and rubber products have a 90 day warranty. All warranties are to the original purchaser with proof of purchase only. Such obligations under this warranty shall be limited to the repair or replacement, at JDI's discretion, of any assembly or part which upon examination by JDI proves to be defective. Any costs of removal, installation, reinstallation or freight charges are expressly excluded from this warranty. This warranty covers only manufacturers defects, and does not cover product finish or damage resulting from abuse, misuse, negligence, racing, alteration, accident or damage in transit.

All returns must be pre-authorized by JDEI and accompanied with a Return Goods Authorization Number (RGA) and a dated proof of purchase. Returns must be made within 90 days of purchase, shipped prepaid, packaged in original cartons to prevent damage in shipment and sent to JDI, 3231 NW Park Dr., Knoxville, TN 37921 Returns without an RGA# will be refused.

This warranty is expressly in lieu of all other warranties, expressed or implied, including the implied warranties of merchantability and fitness for use. This warranty gives you specific legal rights including other rights that vary from state to state. Some states do not allow limitations on how long an implied warranty lasts, or do not allow the exclusion of limitation of incidental or consequential damages, so the above limitations and/or exclusions may not apply to you.